

Installation Instructions

Alpha Premier Pack Pro

(Part No. 3.028421)

For use with Alpha condensing boilers




Fig 1. Kit contents

1. INTRODUCTION

The Alpha Premier Pack Pro is only suitable for use with Alpha condensing boilers originally supplied with *compression* isolation valves only, and must be installed in accordance with these instructions and the installation instructions supplied with the boiler.

The kit comprises of a wall jig fitted with a magnetic cyclone and pipe clips, wall template, flow and return split tails, bottom tray, screw pack and wall spacers. The wall jig has been designed to be fitted to the wall before the boiler, allowing the pipework to be pre-fitted. The pipework can be installed vertically upwards and downwards using the copper tail connections supplied on the jig.

Note: As the wall jig adds 45 mm to the depth of the boiler, clearances and flue measurements need to be adjusted accordingly.

2. INSTALLATION

a. Fit the Wall Jig - See Fig. 2

Tape the wall template to the wall in the required position, making sure it is level. Mark the positions of the eight fixing holes for the wall jig as shown on the template and mark the flue position.

Out of the eight holes marked choose four that are suitable then drill the four holes using a 10 mm drill. Insert the wall plugs provided or use suitable fixing for the wall material.

If a vertical or side flue is to be used, ensure that 45 mm is added to the distance from the centre of the flue hole to the wall on which the boiler is to be mounted. This is to allow for the depth of the wall jig. For horizontal flues use a 110 mm core drill cut the hole for the flue.

Secure the wall jig to the wall using the screws provided or suitable fixings for the wall material, ensuring it is level and flat against the wall. The wall spacers supplied may be placed between the wall and the jig if the wall is not flat.

Note: the jig must be flat against the wall and the boiler flat against the jig and ensure the sides A and B of the jig are vertical.




Fig. 2

b. Pipework Connections To Jig- See Fig. 3

Connect the system pipework to the jig using the copper pipework tails supplied.

Gas/Hot/Cold Water

Gas hot/cold water copper tails may be turned upwards or downwards to suit piping from above or below.

CH Return

- The CH return copper tail (fitted to the Cyclone filter) is supplied ready for bottom exit pipework.
- For top *and* bottom exit CH return pipework installations, the factory fitted factory soldered blanking disc will need to be carefully cut off.
- For top exit *only* pipework the factory soldered blanking disc should be carefully cut off and the downward connection then blanked off/used as a drain off point, etc. by the installer.

CH Flow

- The flow copper tail is supplied ready for bottom exit pipework.
- For top *and* bottom exit CH flow pipework installations, the factory fitted factory soldered blanking disc should be carefully cut off.
- For top exit *only* pipework, unscrew the jig retaining clamp, rotate the CH flow copper tail so the outlet faces upwards and replace the jig retaining clamp.

Notes:

Ensure pipework is adequately clipped and installed straight and true, otherwise later fitting of the boiler/isolation valves may not line up correctly.

Clips are provided on the jig for securing the pipework at the rear of the boiler for top exit installations.

When soldering pipework into the copper tails, ensure that the boiler/isolation valve are NOT fitted, otherwise damage may be caused.

Thoroughly flush all pipework as described in the instructions supplied with the boiler.




Fig.3

Note: When fitting a system boiler the cold mains and DHW connections on the jig are not used and can be removed.

c. Fit the boiler to the Jig - See Fig. 4

Lift the boiler and lower it onto the bracket at the top of the jig (1), whilst keeping the bottom of the boiler held forward. When the boiler is located on the top bracket, let it rest against back onto the jig (2).




Fig.4

d. Fit boiler isolation valves

The compression isolation valves supplied with the boiler should be used. Remove the compression nuts and olives from the boiler isolation valves and fit to the copper tails on the jig (see Fig.5). Fit the isolation valves starting from the CH Flow (right) through to Gas (left) and tighten the compression nuts. Insert the washers provided between each union connection and tighten the joints.

Note: Check **all** connections are tight.



Fig.5

e. Complete installation


Connect the flue, connect the electrical supply, fill the boiler and commission the system as described in the instructions supplied with the boiler.

f. Fitting the bottom tray and pipework cover


A bottom tray and Cyclone filter cover extension are supplied with the Premier Pack Pro.

Offer the extension up to the bottom cover and fix into position using the 4no. screws provided.

Clip the whole assembly to the bottom of the boiler casing, and secure to bottom of boiler casing with 1no. screw per side



Cleaning the Magnetic Cyclone (yearly service)



1. Close the isolation valves connected to the cyclone and the boiler return.
2. Place a bucket underneath the Cyclone and remove the retaining clip by pulling it forwards with a pair of pliers.
3. Pull the magnet downwards to withdraw it from the Cyclone body; a small amount of water will flow out of the Cyclone.
4. Using a cloth wipe any magnetite from the magnet.
5. Reassemble in reverse order

Alpha
HEATING INNOVATION

Alpha Therm Limited.
Nepicar House, London Road, Wrotham Heath,
Sevenoaks, Kent TN15 7RS
Tel: 0344 871 8764
email: info@alpha-innovation.co.uk
website: www.alpha-innovation.co.uk

part no. 1.041339 rev. ST.003465/000